

Hole Drilling Guide for Rail System

Step 1: Match this hole up with the center hole in the base,
then tape the guide onto the base.



Step 2: Pound a nail or Brad-point drill bit in the center of each hole.
Use a 1/4 inch drill bit to drill all 4 holes in the base using either a handheld
drill or a drillpress is even better to make vertical holes.



Step 3: Countersink the bottom of each hole like the center hole.
A really good counter sink if you don't have one:
KEO 53512 Cobalt Steel Single-End Countersink 82 Degree Angle 1/2" body.